




# FTU-100

FiberTwist-Series  
Installation Guide

## In the box



warranty seal



zip ties



adhesive  
foam



wall plugs  
& screws




cover  
screw



splice  
holders



Baseplate



Fiber Management Unit  
(FMU) with coupler




Transparent demarcation cover

## Installation guide

### Choose configuration

- Choose one of the three ingress ports to use for the feeder fiber.
- If using ingress port 1 or 2, if using ingress 1 please cut out the oblong in the baseplate. The oblong for ingress 2 this is already cut out by default.
- For a patch-out, cut out the rectangle at the bottom of the baseplate.
- Insert 2 zip ties in the set of holes matching your chosen configuration.



- Ingress 1
- Ingress 2
- Ingress 3
- Patch-out


### Mount FTU to the wall

De-assemble the FTU, so that the baseplate and FMU are separated. Use the drilling template to mount the baseplate to the wall.

The baseplate can also be mounted directly on a wall junction box.

The drilling template is available on

<https://genexis.eu/download-portal/#fibertwist>




### Attach pigtail or patch cable


- Remove the SC/APC coupler from the FMU.
- Take the protective cap off the top end of the coupler and off the fiber connector, and plug the fiber connector into the coupler.
- Put the coupler and fiber back in the FMU.

There is only one correct way to put the connector back in the FMU:

- The slots must be facing upwards.
- The single metal clip on the right hand side must face towards the middle of the FMU.

Clip






### **Attach feeder fiber**

- If using ingress ports 1 or 2, insert the zip ties through the appropriate set of holes.
- Strip the outer sheath off the feeder fiber.
- If required, install a gasblocker. The gasblocker should rest in the recess.
- Peel the backing off the foam padding before wrapping it around the base of the feeder fiber.
- Position the feeder fiber in the FMU and secure in place using the zip ties. Trim the excess ends off the zip ties.

### **Splice fiber(s)**


- Place the appropriate splice holder.
- Splice the feeder fiber and pigtail together
- Place the splice in the splice holder.
- Store the overlength fiber in the FMU.
- Perform any tests required to guarantee the quality of the splice.



### **WDM combiner** (optional)

A WDM combiner is used for terminating a network with CATV services on a separate RF-overlay fiber. Depending on the model it will be provided with a pre-installed WDM combiner. To install:

- Roll out the Data and CATV fibers.
- Splice these two pigtails to the corresponding feeder fibers.
- Place the two splices in the splice holder.
- Store the overlength fibers in the FMU.
- Perform any tests required to guarantee the quality of the splices.




### **Patch-out** (optional)

The device supports the ability to add patch-out fiber cables. Depending on the model these couplers and/or pigtails are pre-installed in the FMU.

- Connect the pigtail(s) to the patch out coupler.
- Splice the pigtail(s) with the feeder fiber(s).
- Place the splices in the splice holder.


Note: the number and type of patch out options depends on the specific FTU model.



### Patch-in (optional)


The device supports the ability to patch in fiber cables. These connectors are pre-installed in the FMU.

- Please connect the fiber patch cable from the third-party FTU to the patch-in port of the FiberTwist FTU. Depending on the model, you need to place an SC or LC connector.



### Finish installation

- Remove the remaining protective cap from the FiberTwist coupler.
- Place the FMU with the installed fibers on the baseplate.
- Click the transparent cover on the baseplate and FMU.
- Fasten the cover to the baseplate with the screw provided.
- If required, place a seal over the screw.
- Install the active unit or blind cover.



Revision 1.0 August 2020, Copyright © 2020 Genexis B.V. All rights reserved.

Genexis assumes no responsibility for any inaccuracies in this document. Genexis reserves the right to change, modify, transfer, or otherwise revise this publication without notice.